

## Three-Finger Reboot Instructions


Q: What is a three-finger reboot?

A: A three-finger reboot resets the chromebook OS and software back to its factory defaults.


Q: When should I do a three-finger reboot?

A: A three-finger reboot should be performed to fix any major, software related issue that may arise, such as sound or connectivity issues.


**Step 1:** Hold down the Power, Escape, and Refresh buttons until the screen turns black.




**Step 2:** When prompted for a recovery USB Stick or SD card, press CTRL and D keys.




**Step 3:** The next screen will say that OS verification is off. Press enter to progress to the next screen.




**Step 4:** The next screen will have an image of a chromebook with a red “!” over it. Press enter.




**Step 5:** The screen will change to an image of a chromebook with a green check mark on it. The screen will automatically progress to the next screen. Press the blue “Let’s Go” button to continue.




**Step 6:** The next screen will require you to select your internet network and login with your password (this is with the school's network, you will do this with your home network)




**Step 7:** The next screen will ask you to accept the terms and services.



**Step 8:** Wait until the “Enterprise Enrollment complete” screen appears. Click “Done”.



**Step 9:** Press “Add Person” to bring up the login screen.



**Step 10:** Login. Your child's username is the last 2 numbers of their graduation year, followed by the first 4 letters of their last name and the first letter of their first name (ex. 31smitj). All lowercase letters. Their password is archers.

